



Activating your PME Ghost Ring

- 1) If your vehicle is fitted with an optional folding accelerator pedal please ensure that it is in the upright position before activating the Ghost Ring.
- 2) To activate your Ghost Ring start your vehicle and toggle switch 'A'. The red LED will illuminate to confirm your Ghost Ring is now switched on.
- 3) You are now required to apply the brakes of your vehicle by firmly applying pressure to the hand controls brake lever "B" in the direction of the red arrow
- 4) Your Ghost Ring is now ready for use. Before shifting your transmission into drive smoothly rotate the Ghost Ring 'A' in the direction of the arrows to confirm your Ghost Ring is activated.
- 5) The Ghost Ring can be deactivated if your vehicle is used by another driver by toggling switch 'A' so that the red LED is no longer illuminated.

Note: If required switch 'B' can be toggled while the Ghost Ring is in operation to reduce the sensitivity of the accelerator input by **50%**. This is useful when parking, driving on slippery surfaces or during tight manoeuvres.

PME can not be held responsible for any damages or injury caused by incorrect use of the Ghost Ring. Please ensure your license is endorsed for use of this adaptive device. If you are unsure contact your local motor authority.

It is imperative that during routine maintenance or whenever your vehicle is operated by a driver that is not endorsed to use this adaptive device, that the PME Ghost Ring is disabled by toggling Switch A in the off position and returning the folding accelerator pedal to the original position (if fitted).

PME recommend periodic maintenance and visual inspection of the Electronic Radial Hand Control at 6 monthly intervals.

Problem Management Engineering Pty Ltd, 2017
(02) 9482 2808
6 Kookaburra Road, Hornsby Heights NSW 2077
Info@pmeautoconversions.com.au
pmeautoconversions.com.au
MVRL 30140


Located to the Right or Left of the steering wheel (depending on vehicle)




Switch A



Switch B





ACCELERATOR UP
(HAND CONTROL IN USE)

